Autonics

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- A symbol indicates caution due to special circumstances in which hazards may occur.
- **Warning** Failure to follow instructions may result in serious injury or death.

Safety Considerations

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.(e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime / disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, economic loss or fire.
- 02. Do not use or store the unit in the place where flammable / explosive / corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.
- Failure to follow this instruction may result in explosion or fire. **03. Install the device in panel, and ground to the bolt for grounding separately.** Failure to follow this instruction may result in fire or electric shock.
- Failure to follow this instruction may result in fire or electric shock.
 64. Be sure to install, set, and combine the product with a machanical control system by a qualified user operator.
- When a non-user operator installs, sets, and combines the product with a mechanical control system, the product does not work as intended, resulting in personal injury, economic loss or fire.
- 05. When installing or moving the product and changing the position of the power module, hold the body to move it. Do not hold the input power terminal block or the transparent terminal block protection cover (transparent). Separation of the terminal block or cover from the body may result in product damage or personal injury due to falling.
- **06.** Do not connect, repair, or inspect the unit while connected to a power source. Failure to follow this instruction may result in fire or electric shock.
- **07. Check 'Connections' before wiring.** Failure to follow this instruction may result in fire.
- Plante to follow this instruction may result in personal injury, economic loss or fire with product malfunction.
- **09. Do not disassemble or modify the unit.** Failure to follow this instruction may result in fire or electric shock.
- **Caution** Failure to follow instructions may result in injury or product damage.
- 01. Use the unit within the rated specifications.
- Failure to follow this instruction may result in fire or product damage. **02.** Use a dry cloth to clean the unit, and do not use water or organic solvent.
- Failure to follow this instruction may result in fire or electric shock.03. Keep the product away from metal chip, dust, and wire residue which flow into the unit.
- Failure to follow this instruction may result in fire or product damage.O4. Since leakage current still flows right after turning off the power or in the output OFF status, do not touch the load terminal.
- Failure to follow this instruction may result in electric shock **05. Be careful not to injure the edges of the heat sink.**

Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
 Power supply should be insulated and limited voltage / current or Class 2, SELV power supply device.
- Use the product, after 3 sec of supplying power.
- Before use, set the mode and function according to the specification. Since changing the mode / parameter during operation may result in malfunction, set the mode and function after disconnecting load output.
- Set the operating channel of the control setting mode parameters to match the actual wiring. It may result in malfunction. Refer to the product manual for wiring instructions.
- Re-supply the power to the unit after 3 sec of turning off the power. Failure to follow this instruction may result in malfunction.



Modular Multi Channel Power Controller

SPRS Series PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website. The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

- To ensure the reliability of the product, install the product on the panel or metal surface vertically to the ground.
- When installing the power module, use the terminal block protection cover (transparent).
 When installing the front cover of the power module, fit it toward the rear of the analysis of the power module.
- product in accordance with installation groove the angle of 30°.Do not apply excessive force to open the front cover of the power module, the cover may be detached and fall off.
- Install the unit in the well ventilated place.
- While supplying power to the load or right after turning off the power of the load, do not touch the product body and heat sink. Failure to follow this instruction may result in a burn due to the high temperature.
- Use twisted pair wire for communication line.
- RS485 communication cannot be used at the same time as other communications.
 Since inter element can be damaged when using with coil load, inductive load, etc., the inrush current must be under the rated load current.
- To prevent product malfunction due to noise, wire power, control input, communication, and load cables separately.
- When installing close to the load line, use a line filter for the power line and use a shield wire.
 For stable operation, use shield wire for control, alarm, and communication wires.
- Use a ferrite core on the shield wire to cope with EMC.
- Do not use near the equipment which generates strong magnetic force or high frequency noise.
 If environments such as ambient temperature or installation specifications are not satisfied, lower the load rate for use.
- The ambient temperature is -10°C to 40°C. Install a cooling system to ensure that the internal panel temperature does not exceed 40°C. If the ambient temperature unavoidably exceeds 40°C, reduce the load current.
- The power modules with different rated currents can be combined and connected. Connect the power modules to the right of the control module in ascending order of current capacity.
 Failure to follow this instruction may result in malfunction.
- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Altitude max. 2,000 m
- Pollution degree 2
- Installation category III

Cautions during Installation

High Temperature Caution

While supplying power to the load or right after turning off the power of the load, do not touch the body and heat sink. Failure to follow this instruction may result in a burn due to the high temperature.



When installing multiple the power controller, keep space for heat radiation. • Width / Length: ≥ 100 mm

- Separation distance between sets: \geq 80 mm
- Up to 9 sets of connectivity

(power distribution control)

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

Control Module

SPRS -	- 0	
• Module CM: Control module	Communication R: RS485 EC: RS485 + EtherCAT	CL: RS485 + CC-Link PN: RS485 + PROFINET
Power Module		
SPRS -	- 0	8
Module No mark: Power module	Rated load voltage F: Free voltage	Rated load current Number: Rated load current (unit: A)

Product Components

- Product (+ bracket), Instruction manual
- [Control module] Module connection ribbon cable (2 mm pitch, 24-pin) × 1, Power connector × 1, Control signal / communication connector × 1, Alarm output connector × 1
 - [CC-Link comm. model] CC-Link connector imes 1
- [Power module] Module connection ribbon cable (2 mm pitch, 24-pin) \times 1, FAN power connector \times 1, Feedback signal connector \times 1, Terminal block protection cover \times 2

Software

Download the installation file and the manuals from the Autonics website.

DAQMaster

It is the comprehensive device management program for Autonics' products, providing parameter setting, monitoring and data management.

Cautions during Wiring

Ferrule terminal



Unit: mm, Cable specification: AWG 24 - 16
Applicable connector terminal

Control module	Power connector Control signal / Comm. connector Alarm output connector [CC-Link Comm. model] CC-Link connector
Power	Feedback signal connector

module FAN power connector, FAN connector terminal

Copper pipe terminal

- Unit: mm, Use copper tube terminal certificated by UL.
- Be sure to use a copper pipe terminal with an insulating sleeves (tubes) that meets a dielectric strength of 600 V or more.

 [Power module] Cable / tightening torque spec. is different depending on the model based on the rated load current.
 Be sure to check as below.



1	Be sure to check as below.							
JĪ	Pated load	Copper	pipe ter	Cable	Tightening			
)	current (A)	A	В	L	(mm ²)	torque (N m)		
	25 / 40 / 55 / 70	M6	≤ 13	≥ 40	25	5.6 to 6.0		
	90/110/150/180	M8	≤ 25	≥ 64	95	13.6 to 14.5		
	200/250/350	M12	≤ 40	\geq 92	240	47.0 to 50.0		
	400 / 500 / 600	M12×2	≤ 35	≥ 78	185×2	47.0 to 50.0		

Specifications

(packaged)

(1.26 kg

(2.62kg

Series	SPRS Series		
Control phases	Single-phase control, single-phase dual control, 3-phase control (wiring and parameter setting)		
Rated load voltage	Free voltage 220 - 490 VAC~ 50 / 60 Hz		
Permissible voltage range	±10 % of rated load voltage		
Load rated frequency	50 / 60 Hz \pm 3 Hz (frequency auto identification)		
Rated load current	25 / 40 / 55 / 70 / 90 / 110 / 150 / 180 / 200 / 250 / 350 / 400 / 500 / 600 A		
Min. load current	1 A		
Display method	5 digit 11 segment LCD (white) $ imes$ 4, Output BAR		
Auto control input Current: DC 4 - 20 mA × 4 ch (input impedance: 100 Ω) Voltage: 0 - 5 / 1 - 5 / 0 - 10 VDC== × 1 ch External adjuster: 10 k Ω Communication: R5485 / EtherCAT / CC-Link / PROFINET			
Manual control input Parameter setting			
bigital input (DI) RUN (short) / STOP (open), MAN (short) / AUTO (open), Alarm reset (short) / Inactivate (open), Not used (4 ch)			
Alarm output 8 relay contact output (parameter setting) 250 VAC~ 2 A / 30 VDC== 3 A 1a resistance load			
Comm. output	RS485 / EtherCAT / CC-Link / PROFINET model		
Cooling method Natural cooling ⁽¹⁾ : 25 / 40 A, Forced cooling (with cooling far 70 / 90 / 110 / 150 / 180 / 200 / 250 / 350 / 400 / 500 / 600 A			
Certification			
SCCR Rating	100 kA (UL certification)		
01) Forced cooling is available b	y installing FAN separately.		

Control method Phase control Cycle control Normal / Constant current / Fixed cycle / Variable cycle / Power distribution control Control mode Constant voltage / Constant power feedback Applied load Resistance load Resistance load, inductive load Output range 2 to 98 % 0 to 100 % **Output accruacy** Varies by control mode Within \pm 10 % F.S. of rated load Normal voltage Constant current / Within ± 3 % E.S. of rated load voltage / power feedback current / voltage / powe Control module power 24 VDC= supply Permissible voltage 90 to 110 % of power voltage range Fan power supply 24 VDC= Control module: \leq 7 W Power consumption power module: each \leq 2 W (FAN power separately Insulation resistance \geq 200 M Ω (500 VDC= megger) Between the charging part and the case: 3,000 VAC ~ 50 / 60 Hz for **Dielectric strength** 1 min Output leakage current \leq 10 mArms Noise immunity \pm 500 V square wave noise (pulse width: 1 $\mu s)$ by the noise simulator Memory retention \approx 10 years (when using non-volatile semiconductor memory type) 0.5 mm double amplitude at frequency of 5 to 55 Hz in each X, Y, Z Vibration direction for 2 hours 0.5 mm double amplitude at frequency of 5 to 55 Hz in each X, Y, Z Vibration (malfunction) direction for 10 min Ambient temperature -10 to 40 °C, storage: -20 to 70 °C (no freezing or condensation) Ambient humidity 35 to 85 %RH, storage: 35 to 85 %RH (no freezing or condensation) Power module Control Module 25/40/55/ 90/110/ 200 / 250 / 400 / 500 / module 70 A 150/180A 350 A 600 A unit weight 0.76 kg 2.04 kg 3.96 kg 6.10 kg 13.26 kg

(7.14kg

(14.82kg)

(4.72kg

Derating Curve



Ambient temperature [°C]

Communication Interface

Modbus RTU

Comm. protocol	Modbus RTU (16 bit CRC), Modbus ASCII
Application standard	Compliance with EIA RS485
Max. connection	31-unit (address: 1 to 99)
Comm. synchronous method	Asynchronous
Comm. method	2-wire half duplex
Comm. distance	\leq 800 m
Comm. speed	2,400 / 4,800 / 9,600 (default) / 14,400 / 19,200 / 38,400 / 57,600 / 115,200 bps
Comm. response time	0 to 9999 ms (default: 0 ms)
Start bit	-
Data bit	8 bit (fixed)
Parity bit	None (default), Even, Odd
Stop bit	1 bit (default), 2 bit
EEPROM life cycle	\approx 100,000 operations (Erase / Write)

EtherCAT

Comm. specifications	EtherCAT
Association approval ⁰¹⁾	Ethercat
Connection cable	CAT5e class or over (Shield type: SF/FTP, S/FTP, SF/UTP)
Max. comm. distance	Within 100 m distance between nodes
Max. buad rate	10 / 100 Mbps
Topology	Star, Line, Tree

01) EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany CC-Link

Comm. specifications	CC-Link Ver.2.0
Association communed	<u>~</u>

Association approval	CC-Link			
Station type	Remote Device station			
Connection cable	CC-Link Exclusive Cable			
Baud rate	156 k, 625 k, 2.5 M, 5 M, 10 M bps			
Station number	01 to 64			
No. of occupied station	1 station occupied, 2 station occupied			
Max. Comm. distance	Depending on baud rate			
PROFINET				
Ethernet standard	100BASE-TX			
Association approval				
Cable speccifications	Cat 5 over STP (Shield Twisted Pair) Ethernet cable			
Transmission rate	100 Mbps			
Cable length	\leq 100 m			
GSDML file	Download the GSDML file from the Autonics website			

Ethernet standard	100BASE-TX
Association approval	00000 8860
Cable speccifications	Cat 5 over STP (Shield Twisted Pair) Ethernet cable
Transmission rate	100 Mbps
Cable length	\leq 100 m
GSDML file	Download the GSDML file from the Autonics website

Module Connection

- Up to 4 power modules can be connected and controlled based on 1 control
- module. Power modules with different rated load current capacities can be used. • The control module must be installed on the leftmost side.
- When installing multiple modules, connect the concave (凹) of the lower right
- bracket / the convex (凸) of the lower left bracket. • For more information about the control module + power modules connectivity, follow the Autonics website.
- Use the module connection ribbon cable to connect between modules.
- On power modules, connect the above module connector to the left module and the below module connector to the right module.
- After connecting the module connection ribbon cable, it is possible to close the front cover by organizing the cable according to the inner groove.



• An error in the module connection may result in a module connection error alarm.

Dimensions

For the detailed drawings, follow the product manual or Autonics website.

Manual

For proper use of the product, refer to the manuals and be sure to follow the safety considerations in the manuals. Download the manuals from the Autonics website.

Dimensions

• Unit: mm, For the detailed drawings, follow the Autonics website.

Control Module

• It is based on the model with RS485 communication(SPRS-CM-R).



Power Module

• Rated load current 25 / 40 / 55 / 70 A model

It is based on a model with rated load current 55 / 70 A. The model with rated load current 25 / 40 A does not have a cooling fan.





• Rated load current 90 / 110 / 150 / 180 A model





• Rated load current 200 / 250 / 350 A model



• Rated load current 400 / 500 / 600 A model





Control Module + 4 Power Modules Connection

- The power modules with different rated currents can be combined and connected.
- Connect the power modules to the right of the control module in ascending order of current capacity.
- The demensions may vary depending on the module connection.
- Unit: mm
- Control module + Power module (25 / 40 / 55 / 70 A)





Control module + Power module (200 / 250 / 350 A)





5. × 1000 indicator (green) (only LINE1)

Turn ON for over 6 digit accumulated power. Multiply 1000 times for the present value. E.g.) 1,000 kWh, \times 1000 means 1,000,000 kWh when turned ON.

6. PV / SV display part (white)

Turns ON the monitoring value. Display range: 0000.0 to 9999.9 (fixed decimal point) It is possible to set the value for each LINE in the monitoring setting mode.

7. Unit indicator (green)

kWh ⁰¹⁾	kW ⁰²⁾	v	%	A	mA	°C	Hz	Ω
Accumulated power	Power	Voltage (RMS)	Input / Output	Input / Output current	Control input current	Heatsink temp.	Input power freq.	Load resistance

01) Only LINE1. 2) For LINE2 to 4

8. Setting keys $(\equiv, \Box, \blacktriangle, \blacktriangledown)$

Front cover inner connector

A. Module connector

Connect the module connection ribbon cable to the power module.

B. Control signal / Comm. connector C. Alarm connector 0226-0712, Dinkle 0159-0426, Dinkle — A (+) PDC 1 2 1 Alarm 1 CH1 4-20m/ NO B (-) 2 3 AGND COM 1 NO 3 A (+) Alarm 2 CH2 4-20r

RS485 4 - в (-) Alarm 3 AGND 8 5 COM 2 9 10 VR (10kΩ) CH3 4-20 + INPUT 0-5VDC= 6 Alarm 4 VR 12 11 AGND 1-5VDC= 7 Alarm 5 0-10VDC= + 13 AGND 14 8 СОМ 3 CH4 4-20 ΝO 15 AGND DI_IN1 16 -50 9 Alarm 17 DGND DI_IN2 18 10 -50 Alarm 7 11 COM 4 19 DGND DI_IN3 20 -00 ΝO 12 Alarm 8 21 DGND DI IN4 22 -50-AUTO (open) / 23 DGND ᠊᠊ᡠ 24 MANUAL (short) STOP (open) / 25 DGND ________ 26 RUN (short)

D. RESET button

Reset the operation or alarm.

E. USB connector (do not use)

It is for maintenance of manufacturer. Do not use this connector.

Communication Connector

• [EtherCAT comm. model]

[CC-Link comm. model]

3

• [PROFINET comm. model]

1. PROFINET comm connector (LINK2/LINK1) RJ45						
Pin	Function	Pin	Function			
1	TD+	5	-			
2	TD-	6	RD-			
3	RD+	7	-			
4	-	8	-			
2. RJ45 LED 1 (green) / LED 2 (yellow)						
LED1 Turns ON: LINK input						
LED2 Turns ON: TX/RX input						

3. BF (red) / SF (red) indicator

BF: Bus Fail / SF: System Fail

[Control Module] Digital Input (DI_IN 1 to 4) Setting

Digital input (DI_IN1 to DI_IN4) pins can be connected to external devices (e.g., PLC) to perform set functions based on contact operations. Functions can be configured for each pin of '1-14. digital input'.

The digital input (DI_IN1 to DI_IN4) performed based on the wired channels of the power module connected to the right side of the control module. Ex) 1P4 wiring: CH1 \rightarrow DI IN1 / CH2 \rightarrow DI IN2 / CH3 \rightarrow DI IN3 / CH4 \rightarrow DI IN4

3P1P1 wiring: 3P1(CH1) → DI_IN1 / P1(CH4) → DI_IN4

Function	Display	Contact operation			
	Display	ON	OFF		
Not used	DISAL	Not used			
RUN / STOP	R_S	RUN STOP			
AUTO / MAN	A_M	MANUAL AUTO			
Alarm reset	ALM_I	Alarm reset Inactivate			

2

_

1. EtherCAT comm. connector (OUT/IN) **RJ45** Pin Function Pin Function

1	TD+	5	-
2	TD-	6	RD-
3	RD+	7	-
4	-	8	-
. RJ	45 LED 1 (greei	n)

LED1 Turns ON: Link / activated input

3. ERR (red) / RUN (green) indicator

1. CC-Link comm. connector 0150-3004, Dinkle Pin Function Pin Function DA DB SLD. DG 4

3. ERR (red) / RUN (red) indicator

Load Output Formula

уре	Input		Formula				
	Current	DC 4 - 20 mA					
[1-5VDC==					
uto control	Voltage	0 - 5 VDC==	Load output [%]				
		0 - 10 VDC==	= (Control input [%] \times Output slope [%])				
	RS485 / EtherCAT / CC-Link / PROFINET	0 to 100.0 %	+ Offset				
	External adjuster	0 to 10 kΩ					
Ianual control MANU)	ol Parameter	0 to 100.0 %	Load output [%] = Parameter SV [%]				
uto control \UTO) lanual control /ANU)	Current Voltage RS485 / EtherCAT / CC-Link / PROFINET External adjuster DI Parameter	DC 4 - 20 mA 1 - 5 VDC== 0 - 5 VDC== 0 - 10 VDC== 0 to 100.0 % 0 to 10 kΩ 0 to 100.0 %	Load output [%] = (Control input [%] × Output slope [% + Offset Load output [%] = Parameter SV [%]				

[Control Module] Initial Display When Power is ON

When power is supplied, after the entire display will turn on for 2 sec. Next, it will flash for 0.5 seconds to indicate the model specification (comm. specification, firmware version). Once this process is complete, the product will enter its RUN mode.

	1. All displays	2. Model spec.	3. Run mode
LINE1	8888.8	ModEL	0.0
LINE2	8888.8	PN (Communication)	0.0
LINE3	8888.8	FW	0.0
LINE4	8888.8	1 (Firmware version)	0.0

[Control Module] Mode setting

• It is based on Run mode entering / return.

Mode	Entering	Return
Control setting mode	[≡] 2 sec.	[≡] 2 sec.
Alarm setting mode	$[\equiv +\Box]$ 2 sec.	[≡] 2 sec.
Monitoring setting mode	[≡ + ▲] 2 sec.	[≡] 2 sec.
BAR output phase setting	[=]	Auto
Switch to monitor display on LINE1	[□]	Auto
Display current control status in forward direction on LINE1 screen	[▲]	Auto
Display current control status in reverse direction on LINE1 screen	[▼]	Auto
Alarm RESET	[▼] 2 sec.	Auto
EtherCAT status monitoring mode	[≡ + ▼] 2 sec.	[≡] 2 sec.
Manual control input	[□ + ▼] 2 sec.	[≡] 2 sec.
Parameter reset	[▲ + ▼] 2 sec.	[≡] 2 sec.

[Control Module] Alarm

• When an alarm occurs, the following message will flash on LINE 1, and the configured relay (A contact) output will turn ON. If multiple alarms occur, the messages will flash sequentially.

• It is possible to set enabling / disabling the alarm, setting range, delay time, output, and return options with parameter adjustment.

LINE 1 display	Alarm	Output (default)	Alarm release ⁰¹⁾		
o C.A	Overcurrent				
o V.A	Overvoltage	Stop (SCK OFF)			
o E W.A	Heatsink overheat	Maintain (normal operation)			
o E P.A	Heatsink overheat protection	Stop (SCR OFF)	Re-supply power		
НЕБК.Я	Heater brake		Press [RESET]		
d L F.A	partial heater brake	Maintain (normal operation)	Press [▼] for over 2 sec.		
5 C R.A	SCR error		Set the DFIN parameter ALM_1		
F U S E.R	Fuse brake	Stop (SCK OFF)	input torminal		
FANA	FAN error	Maintain (normal operation)	Set ENABL = OFF of each alarm		
F R Q Y.A	Frezuency error		parameter.		
L P W R.A	Input low voltage	Stop (SCR OFF)			
PM_8	Module connection error				
UL.A	Load imbalance	Maintain (normal operation)			

01) If the alarm occurrence condition is not removed, the alarm is re-occur even if the alarm release method is applied.

[Control Module] Parameter Setting

 Some parameters are activated / deactivated depending on the model or setting of other parameters.

Control setting mode

Parameter	LINE1
Operating channel	oP-5
Control input	INPUE
Load type	LoAd
Control mode	o P E R
Feedback control time	Fdb-E
PI coefficient	PI - G
Soft start / up / down	SoF-E
Output high / low-limit	oUt-L
Output current limit	E-LM
Input slope correction	SLoPE
Input offset correction	oFSEŁ
Partial heater break scan	dLF
Power distribution control	PGC
Digital input	di SEE
RS485 Comm.	RS48S
CC-Link Comm.	C L
Parameter reset	RSE-P
Accumulated power reset	RSE-1
Parameter lock	LoEK
Manual control input	MANU

Alarm setting model	ode
Parameter	LINE1
Overcurrent alarm	o C.A
Overvoltage alarm	o V.A
Heatsink overheat alarm	o E W.A
Heatsink overheat protection alarm	o E P.A
Heater break alarm	НЕБК.А
Partial heater break alarm	d L F.A
Element (SCR) error alarm	S C R.A
Fuse break alarm	F U S E.A
FAN error alarm	F A N.A
Frequency error alarm	F R Q Y.A
Input low voltage alarm	L P W R.A
Module connection error alarm	PM - CN.A
Load imbalance alarm	UL.A
Alarm log	L o G.A
System time	E-SEE.A
Monitoring setting	ng mode
Parameter	LINE1
LINE 1 monitor display	LINEI
LINE 2 monitor display	LI NE 2
LINE 3 monitor display	LI NE 3
LINE 4 monitor display	LINEY
Current time	EIM-E
Alarm history	ALM-d

Troubleshooting

ai agn

[Control Module] Parameter Setting_Control Setting Mode

Some parameters are activated / deactivated depending on the model or setting of other parameters. Refer to the description of each parameter.

- Do not change parameters during output. • If any key is not entered for 60 sec in each parameter, it returns to RUN mode.
- [≡], [▲], [▼] key: Changes LINE
- [] key: When LINE1 flashes, saves current set value and moves to the next parameter. Changes set values.
 - Changes setting digits.
- [\blacktriangle], [\blacktriangledown] key: Changes number when numerical set value is changed
- Bold specifications for each parameter setting range are factory default.

1-0. Entering In the RUN mode, press the [\equiv] key for more than 2 seconds to enter.

1-1. Operating		OP-S: Operating channel							
channel	LINE1	Set the configuration to match the actu Refer to the load wiring for the wiring m	al wiring o ethod.	f the power module. Failure to	follow this	s may result in mal	function.		
	LINE2	 1P1: Single-phase control + 1 Power module (Load 1-channel) 1P2: Single-phase control + 2 Power modules (Load 2-channel) 1P3: Single-phase control + 3 Power modules (Load 3-channel) 1P4: Single-phase control + 4 Power 	2P1: Sir 2-r 2P2: Sir 2-r 2P1P1:	igle-phase dual control + 1 Pov nodule (Load 1-channel) igle-phase dual control + 2 Pov nodules (Load 2-channel) Single-phase dual control + 1 f 2-modules + 1 Power module (Load 2-channel)	wer wer Power	3P1: 3-phase cont (3-phase load 3P1P1: 3-phase co of power n (3-phase lo 1-channel)	rol + 3 Power module J 1-channel) ntrol + 3 series controls nodules + 1 power module vad 1-chnnel + load		
		modules (Load 4-channel)	2P1P2:	Single-phase dual control + 1 F 2-modules + 2 Power modules (Laod 3-channel)	Power				
	LINES	-				DELTA: Delta conn	ection		
						STAR: STAR conne	ction		
1.2. Control lineart									
1-2. Control input	LINE LINE Displays the shapped set in the 1.1 enserting shapped OD S								
	LINEZ	4-20: 4 - 20 mA	1-5:1-	5 VDC== 1 channel (Integration)	EX-R: External volu	ume 10 kΩ		
	LINE3	Single-phase: 4 channel / 3-phase: 1 channel	0-5:0- 0-10:0	5 VDC== 1 channel (Integration - 10 VDC== 1 channel (Integrati	n) on)	RS485: RS485 Con F-NET: EtherCAT /	nm. CC-Link / PROFINET Comm.		
	LINE4	CH1: Channel 1 CH2: Channel 2 CH3: Channel 3 CH4: Channel 4	-						
1-3. Load type	LINE1	LOAD: Load type							
	LINE2	Displays the channel set in the 1.1. operating of	hannel OF	D-S.					
	LINE3	RESIS: Resistive load TRANS: Inductive load							
	LINE4	-							
1-4. Control mode	LINE1	OPER: Control mode			0				
	LINE2	Displays the channel set in the 1.1. operating of	hannel OF	P-S.					
		PA: Normal phase control FB.C: Constant c	urrent	FB.V: Constant voltage	FB.W: Co	nstant power	PDC: Power distribution		
	LINE3	mode V-CY: Variable cycle control	phase control (70)	pn		Control			
	LINE4	- 10 to 100 to 110		10 to 44 to 110	10 to 100) to 110	-		
1-5. Feedback control time	LINE1	FDB-T: Feedback control time The time to reach the feedback target (Display condition) 1-4. control mode (value can OPER: FB.C	be controlled. 2 / FB.V / FB.W					
	LINE2	Displays the channel set in the 1.1. operating of	hannel OF	^{D-} S.					
	LINE3	0 to 95 to 100: Slow feedback control time to	ast						
	LINE4	-							
1-6. Pl coefficient	LINE1	PI-G: PI coefficient Controls the time for the output voltage	to reach th	ne steady status and the overs	noot.				
	LINE2	Displays the channel set in the 1.1. operating of PGAIN: P coefficient	IGAIN: I	-S.					
	LINE4	1 to 60 to 300: Slow steady status reach to Fast	1 to 60	to 300					
1-7. Soft start /		SOF-T: Soft start /Soft up / Soft down							
Soft up /	LINEI	Sets the time to reach the set value up	on initial o	or re-output.					
Soft down	LINE2	Displays the channel set in the 1.1. operating o	UP T: S	oft up time		DN T: Soft down t	time		
	LINE3	ST_T: Soft start time The time it takes to reach 100% from th initial 0% output (sec)	e f	Rise time to reach the target va he control value is changed du operation (sec)	lue when Iring	Drop time t when the c during ope	o reach the target value ontrol value is changed ration (sec)		
	LINE4	0 to 3 to 999: Fast target output value reach to Slow	0 to 3 to	o 999: Fast target output value Slow	reach to	0 to 3 to 999: Fast Slov	target output value reach to		
1-8. Output high /	LINE1	OUT-L: Output high / low-limit							
low-limit	LINE2	Protects load to limit output range Displays the channel set in the 1.1. operating of	hannel OF	D-S					
	LINE3	HIGH: Output high-limit value (%)	LOW: O	utput low-limit value (%)					
	LINE4	0 to output high-limit value to 100	0 to out	tput low-limit value to 100					
1-9. Output current	LINE1	C-LM: Output current limit							
umit	LINE2	Displays the channel set in the 1.1. operating of	hannel OF	-S.					
	LINE3	10 to 110 : Output current limit value (%)							
	LINE4 Rated current of the power module × 110 % (e.g., SPRS-F600 model, 660 displayed)								

1-10. Input slope	LINE1	SLOPE: Input slope	correc	tion								
correction		Limits the p	ower su	pplied to the	e load.							
	LINE2	-99.9 to 0.0 to 99.9.	i set in t Input slo	ne 1.1. opera	ating chan on value (9	(hei OP-S.) (h)						
	LINE4	-										
1-11. Input offset		OFSET: Input offse	t correc	tion								
correction	LINE1	It compensa	ates the	offset betwe	en actual	input value	e and measured input	valu	e.			
	LINE2	Displays the channe	l set in t	he 1.1. opera	ating chan	nel OP-S.						
	LINE4	-	input on	iser concette	ni value ()	/0/						
1-12. Partial heater		DI E' Partial heater	brook			_						
break scan	LINE1	(Display condit	ion) 1-1.	. operating c	hannel OF	P-S: 1P1 / 1	P2 / 1P3 / 1P4					
	LINE2	Displays the channe	l set in t	he 1.1. opera	ating chan	nel OP-S.	M.O. Soon range				1	
	LINE3	START: Partial heat break scan	ter	conn load same	ections for heaters of capacity	r partial the (units)	(No alarm for par heater break in th excess range)	rtial he	UP-T: Scan UP	time	DN-T: S	Scan DOWN time
	LINE4	ON: Start OFF: Stop		2 , 3, 4, 5, 6		25	5, 50, 75, 100		0 (OFF), 1 to 1	00	0 (OFF)	, 1 to 100
1-13. Power	LINE1	BDC: Bower distrib	ution	ontrol								
distribution	LINE2	Displays the channe	l set in t	he 1.1. opera	ating chan	nel OP-S.						
control	LINE3	ID: Distribution cont	rol mod	ule ID	Т	-NUM: Tota	al number of distributi	on c	ontrol power m	odules (units,	includin	g Master)
	LINE4	1 (Master), 2 to 36			2	to 4 to 36						
1-14. Digital input	LINE1	DISET: Ditial input										
	LINE2	Displays the channe	l set in t	he 1.1. opera	ating chan	inel OP-S.	A M. AUT	ro / I			l' Alerman	react
	LINE3	-		K_3	NUN/SI	IUP	A_M- AU I	071	MANUANL		I Aldrin i	eset
1-15. RS485 Comm.	LINE1	DS485' DS485 Com	m									
		PROTO: Protocol	ADDR: /	Address	BPS: Co	mm. speec	P-BIT: Parity bit	S-B	IT: Stop bit (bit)	RS-T: Respo	onse	COPY: Writing
	LINE2			code	(bit	t)				waitir (msee	ng time c)	parameters
					24: 2,400)						
		RTU: Modbus RTU			48. 4,800 96 : 9,600	0	NONE: No use					
	LINE3	ASCII: Modbus	1 to 99		144: 14,4	400 200	EVEN: Even number	1 , 2		0 to 9999		YES, NO
		1001			384: 38,4 576: 57,6	400 500						
	LINF4	-			1152:11	.5,200						
1-16 CC-Link Comm												
	LINE1	(Display condition	n) Cont	rol module (CC-Link Co	omm. mod	el: SPRS-CM-CL					
	LINE2	Re-supply powe	r after se	etting to app	ly settings	S. TN: Subsci	iber trunk dialing nun	nher	BALL). Communic	ation sne	ed (bps)
	LINE3	1 to 64			1)		ibei	156	625K 25M	5M 10M	
		-				, z			150	, 02510, 2.510,	5141, 10141	
1 17 Developmenter		1										
reset	LINE1	RST-P: Parameter I	reset 1		5	TART: Star	+					
		noniti no use				LINE1 F	ST: Parameter reset 2					
	LINE2					LINE2	IO: Cancel YES:	Star	t ⁰¹⁾			
						followed	s is executed, INIT blinks by a reboot, and the parar	on the neters	e display, 5 are reset			
	LINE3	-				to delauti						
	LINE4	-										
1-18. Accumulated	LINE1	RST-I: Accumulate	d powe	r reset 1								
power reset		NONE: No use			<u>s</u>	TART: Star	t CT: Asymptoted page		unat 2			
	LINE2					LINE1	VO: Cancel YES:	Star	t			
	LINE3	-			=							
	LINE4	-										
1-19. Parameter lock	LINE1	LOCK: Parameter le	ock									
	LINE2	OFF: No use	ng mod	e lock								
	LINEZ	LOCK2: Alarm setting	g mode	lock								
	LINE3	-										
1-20 Manual country	LINL4	1										
input	LINE1	MANU: Manual con The manual control	trol inp input is	ut activated wł	nen the co	ontrol input	t signal (terminal 24) is	s sho	rted to DGND.			
	LINE2	Displays the channe	l set in t	he 1.1. opera	ating chan	nel OP-S.						
	LINE3	0 to 100: Manual cor	ntrol inp	ut value (%)								
	LINE4	-	1									

[Control Module] Alarm Setting Mode

- Some parameters are activated / deactivated depending on the model or setting of other parameters. Refer to the description of each parameter.
- Do not change parameters during output.
 If any key is not entered for 60 sec in each parameter, it returns to RUN mode.
- [≡], [▲], [▼] key: Changes LINE
- [] key: When LINE1 flashes, saves current set value and moves to the next parameter.
 - Changes set values.
 - Changes setting digits.
- $[\blacktriangle], [\blacktriangledown]$ key: Changes number when numerical set value is changed.
- Bold specifications for each parameter setting range are factory default.

2-0. Entering	In the R	UN mode, press [≡	:+□] ke	eys for more	e than	2 secon	ds to enter.						
2-1. Overcurrent alarm	LINE1	OC: Overccurent a It is possible to (Alarm operatin Overcurrent = ra	l arm protect g condit ated cur	the load, fuse ion) An alarm	e, and e n occur urrent	element fro rs when th upper limi	om overcurrer e set overcurr t (%)	nt. ent is outpi	ut for longer tl	han the	delay time.		
	LINE2	Displays the channe	l set in t	he 1.1. opera	ting ch	annel OP-	S.						
	LINE3	ENABL: Enable	LM ⁻	T-C: Overcurre upper lin (%, based RMS)	ent nit d on	DLY-T: De	elay time (sec)) OUT-S: C d	ontrol output uring alarm	RLY-C	: Relay outp	ut A-	RCY: Alarm return (fixed for 5 sec.)
	LINE4	ON OFF	1 to	110		3 to 5 to	600	STOP: St OUT: Hol	t op d	DISAL RL1/2	_ 2/3/4/5/6/7/8	B 0	N FF
2-2. Overvoltage alarm	LINE1	OV: Overvoltage al It is possible to (Alarm operatin	arm protect g condit	the load from ion) An alarm	n overv n occur	oltage. 's when th	e set overvolt	age is outpi	ut for longer t	han the	delay time.		
	LINE2	Displays the channe	l set in t	he 1.1. opera	iting ch	annel OP-	S.						
	LINE3	ENABL: Enable	LM	T-V: Overvolta upper lim based on	age hit (V, RMS)	DLY-T: De	elay time (sec) OUT-S: C d	ontrol output uring alarm	RLY-C	: Relay outp	ut A-	RCY: Alarm return (fixed for 5 sec.)
	LINE4	ON OFF	20 1	to 550		3 to 5 to	600	STOP: St OUT: Hol	t op d	DISAL RL1/2	 2/3/4/5/6/7/8	0 3 0	N FF
2-3. Heatsink overheat alarm	LINE1	OTW: Heatsink ove (Alarm operat	rheat a	larm dition) An alar	m occ	urs when t	he heatsink te	emperature	exceeds the o	verheat	threshold fo	r longer	than the delay time.
	LINE2	ENABL: Enable	TEM	MP: Overheat (°C)	temp.	DLY-T: De	elay time (sec) OUT-S: C d	ontrol output uring alarm	RLY-C	: Relay outp	ut A-	RCY: Alarm return (fixed for 5 sec.)
	LINE3	ON OFF	50 1	to 60 to 70		3 to 5 to	600	STOP: Sto OUT: Ho	op Id	DISAL RL2/	1/3/4/5/6/7/8	B 0	N FF
	LINE4	-											
2-4. Heatsink overheat	LINE1	OTP: Heatsink ove (Alarm operati	rheat p	rotection ala ition) An aları	irm m occu	ırs when th	ne heatsink te	mperature e	exceeds the ov	/erheat	threshold for	r longer t	han the delay time.
protection alarm	LINE2	ENABL: Enable	TEN	MP: Overheat (°C)	temp.	DLY-T: De	elay time (sec) OUT-S: C d	ontrol output uring alarm	RLY-C	: Relay outp	ut A-	RCY: Alarm return (fixed for 5 sec.)
-	LINE3	ON OFF	70 1	to 80 to 90		3 to 5 to	600	STOP: St OUT: Hol	d	DISAL RL1/2	_ 2/3/4/5/6/7/8	0 3 0	N FF
	LINE4	-											
2-5. Heater break alarm	LINE1	HT_BK: Heater bre (Alarm operating co	ak alar ndition)	m An alarm occ delay time.	curs wh	ien the out	tput exceeds t	he upper lii	mit and currer	nt falls b	elow the low	ver limit i	for longer than the
	LINE2	Displays the channe	l set in t	he 1.1. opera	ting ch	annel OP-	S.						
	LINE3	ENABL: Enable	LMT-O	Upper output limit (%)	LMT-0	C: Lower current limit (A)	DLY-T: D (sec)	elay time	OUT-S: Contr outpu during	ol ut galarm	RLY-O: Rela outr	iy out	A-RCY: Alarm return (fixed for 5 sec.)
	LINE4	ON OFF	5 to 50	to 100	0 to 6	60	3 to 5 to	5 to 600 STOP: Stop OUT: Hold		DISAL RL1/2/3/4/5/6/7		/5/6/7/8	ON OFF
2-6.Partial heater break alarm	LINE1	DLF: Partial heater (Alarm operati (Alarm activati A load quantit	break and cond on cond	alarm ition) An alari ition) A scan .D.Z setting ci	m occu of cont urrent	irs if any trol setting threshold	load becomes is modes 1 to or higher.	disconnect 12 is requir	ed during par ed	allel loa	d operation.		
	LINE2	Displays the channe	l set in t	he 1.1. opera	iting ch	annel OP-	S.						
	LINE3	ENABL: Enable	DE/ alaı	AD.Z: Non-ope rm range (A)	erating	DLY-T: De	elay time (sec	OUT-S: C d	ontrol output uring alarm	RLY-C	: Relay outp	ut A-	RCY: Alarm return (fixed for 5 sec.)
	LINE4	OFF	1 to	3 to 200		3 to 5 to	600	OUT: Ho	op Id	RL2/	1/3/4/5/6/7/8	3 0	n FF
2-7.Element (SCR) error alarm	LINE1	SCR: Element (SCF (Alarm operati	error ng cond	alarm ition) An alar delay ti	m occı ime.	urs when t	he output is b	elow the se	et value and th	ne curre	ent exceeds t	he set th	reshold during the
	LINE2	Displays the channe	l set in t	he 1.1. opera	iting ch	annel OP-	S.		1				1
	LINE3	ENABL: Enable	LMT-O	Lower output limit (%)	LMT-0	C: Upper current limit (A)	DLY-T: D (sec)	elay time	OUT-S: Contr outpu durin;	Itrol RLY-O: Relay put output ing alarm		iy out	A-RCY: Alarm return (fixed for 5 sec.)
	LINE4	ON OFF	0 to 10	0	0 to 3	to 660	3 to 5 to	600	600 STOP: Stop OUT: Hold		DISAL ON RL1/2/3/4/5/6/7/8 OFF		ON OFF
2-8.Fuse break alarm	LINE1	FUSE: Fuse break a	llarm ting con	dition) An ala	arm oc	curs if the	fuse is broker	ı for longer	than the delay	y time o	or if the load	power is	not supplied.
	LINE2	Displays the channe	l set in t	he 1.1. opera	ting ch	annel OP-	S.			,			
	LINE3	ENABL: Enable		DLY-T: Delay	y time	(sec)) OUT-S: Control output during alarm		RLY-O: R	RLY-O: Relay output			Alarm return (fixed for 5 sec.)

STOP: Stop OUT: Hold DISAL RL1/2/3/4/5/6/7/8 ON OFF

3 to **5** to 600

ON OFF

LINE4

2-9. FAN error alarm	LINE1	FAN: FAN error alarm (Alarm operating	condition) An alarm occ not met or if	urs if the F the FAN de	AN operating c	ondition (heats for longer tha	sink temp. n the dela	: ON at 35 °C or hig y time.	;her / C	DFF at 30 °C or lower) is			
	LINE2	Displays the channel se	et in the 1.1. operating c	hannel OP	P-S.								
	LINE3	ENABL: Enable	DLY-T: Delay time	DLY-T: Delay time (sec)		OUT-S: Control output during alarm		elay output	A-RCY: Alarm return (fixed for 5 sec.)				
	LINE4	ON OFF	3 to 5 to 600		STOP: Stop OUT: Hold		DISAL RL2/1/3/4/5/6/7/8		ON Off				
2-10. Frequency error alarm	LINE1	FRQY: Frequency error (Alarm operating	r alarm g condition) An alarm oc delay time.	ccurs if the	load power fre	equency is 0 Hz	, 44 Hz or	lower, or 66 Hz or I	nigher	for longer than the			
	LINE2	Displays the channel se											
	LINE3	ENABL: Enable	DLY-T: Delay time	(sec)	OUT-S: Contr during	ol output g alarm	RLY-O: R	elay output	A-RC	Y: Alarm return (fixed for 5 sec.)			
	LINE4	ON OFF	3 to 5 to 600		STOP: Stop OUT: Hold		DISAL RL2/1/3,	/4/5/6/7/8	ON OFF				
2-11. Input low voltage alarm	LINE1	LPWR: Input low volta (Alarm operatin	age alarm g condition) An alarm o	ccurs wher	n the input volta	age falls below	the lower i	nput voltage limit fe	or long	ger than the delay time.			
	LINE2	Displays the channel se	et in the 1.1. operating c	hannel OP	P-S.								
	LINE3	ENABL: Enable	LMT-V: Lower input voltage limit (V) DLY-T: D	elay time (sec)	OUT-S: Contr durin	ol output g alarm	RLY-O: Relay outp	ut	A-RCY: Alarm return (fixed for 5 sec.)			
	LINE4	ON OFF	100 to 500	3 to 5 to	600	STOP: Stop OUT: Hold		DISAL RL1/2/3/4/5/6/7/8		ON OFF			
2-12. Module connection error alarm	LINE1	PM-CN: Module conne (Alarm operation	ection error alarm ng condition) An alarm for longer If one pov module c	occurs wh than the over modul	en the commur delay time. e is connected a error alarm ma	nication betwee	n the cont channel 1P	rol module and po 4 (requires 4 power	wer me r modu	odule is not connected Jles) is selected, a			
	LINE2	Displays the channel set in the 1.1. operating channel OP-S.											
		ENABL: Enable	DLY-T: Delay time	(sec)	OUT-S: Contr	ol output	RLY-O: R	elav output	A-RC	CY: Alarm return			
	LINE3			during		g alarm				(fixed for 5 sec.)			
	LINE4	ON OFF	3 to 5 to 600		STOP: Stop OUT: Hold		DISAL OI RL1/2/3/4/5/6/7/8 Of		ON OFF				
2-13. Load imbalance alarm	LINE1	UL: Load imbalance a (Display condition) (Alarm operating co	larm 3-phase control ondition) An alarm occu Load imbalanc	rs when th ce ratio = (e load imbaland Max. 3-phase cu	ce ratio is belov urrent - Min. 3-p	v the lowe phase curr	r limit for longer tha ent) × 100 / averaş	an the ge 3-pł	delay time. hase current			
	LINE2	Displays the channel se	et in the 1.1. operating c	hannel OP	P-S.								
	LINE3	ENABL: Enable	LMT-P: Lower limit load imbalance ratio (%)	DLY-T: D	elay time (sec)	OUT-S: Contr durin	ol output g alarm	RLY-O: Relay outp	ut	A-RCY: Alarm return (fixed for 5 sec.)			
	LINE4	ON OFF	5 to 30 to 100	3 to 5 to	600	STOP: Stop OUT: Hold		DISAL RL2/1/3/4/5/6/7/8	8	ON OFF			
2-14. Alarm log	LINE1	LOG-S' Alarm log											
C	LINE2	FNABI : Enable		CLEAN:	Reset								
	LINE3	ON OFF		NONE: START: S	Cancel Start								
	LINE4	-											
2-15. System time	LINE1	T-SFT' System time											
	LINE2	VFAP: Voar	MONTH: Month	DAV. Do	N .	HOUR Hour		MIN' Minute	I	SET' Reset			
	LINE2	2000 to 2100	1 to 12	1 to 31	у	0 to 23		0 to 59		NONE: Cancel			
	LINF4	-	1	1		1		L					

[Control Module] Monitoring Setting Mode

• Some parameters are activated / deactivated depending on the model or setting of other parameters. Refer to the description of each parameter.

- Do not change parameters during output.
 If any key is not entered for 60 sec in each parameter, it returns to RUN mode.
- [≡], [▲], [▼] key: Changes LINE
- [[]] key: When LINE1 flashes, saves current set value and moves to the next parameter.
 - Changes set values.
 - Changes setting digits.
- [\blacktriangle], [\triangledown] key: Changes number when numerical set value is changed
- Bold specifications for each parameter setting range are factory default.

3-0. Entering In the RUN mode, press $[\equiv +\Box]$ keys for more than 2 seconds to enter.

3-1. LINE 1 monitor	LINE1	LINE1: LINE 1 monitor displ	ay						
display	LINE2	CTL-O: Control output value CTL-I: Control input value (% OUT-V: Output voltage (V)	e (%) %)	WATT: Power (kw) I-WAT: Accumulat OHM: Load resista) ed pow ance (Ω	ver (kwh))	CONN: Wirin INPUT: Input TEMP: Heats	g method t channel ink temperature (°C)	
		IN-V: Input voltage (V) AMP: Current (A)		FRQY: Frequency CTL-M: Control m	(Hz) ethod		P_FW: Powe PNAME: Pow	r module FW version ver module model name	
	LINE3	-							
	LINE4	-							
3-2. LINE 2 monitor	LINE1	LINE2: LINE 2 monitor displ	ау						
display	LINE2	CTL-O: Control output value CTL-I: Control input value (9 OUT-V: Output voltage (V) IN-V: Input voltage (V) AMP: Current (A)	WATT: Power (kw) OHM: Accumulate FRQY: Frequency CTL-M: Control m TEMP: Heatsink te	WATT: Power (kw) OHM: Accumulated power (Ω) FRQV: Frequency (Hz) CTL-M: Control method TEMP: Heatink temperature (°C)					
	LINE3	CH1/2/3/4							
	LINE4	-							
2-2 LINE 2 monitor		1							
3-3. LINE 3 Monitor	LINE1	LINE3: LINE 3 monitor displ	ay						
display	LINE2	CTL-O: Control output value CTL-I: Control input value (% OUT-V: Output voltage (V) IN-V: Input voltage (V) AMP: Current (A)	2 (%) (6)	WATT: Power (kw) OHM: Accumulate FRQY: Frequency CTL-M: Control m TEMP: Heatsink te					
	LINE3	CH2/1/3/4							
	LINE4	-							
3-4. LINE 4 monitor	LINE1	LINE4: LINE 4 monitor displ	ау						
display	LINE2	CTL-O: Control output value CTL-I: Control input value (9 OUT-V: Output voltage (V) IN-V: Input voltage (V) AMP: Current (A)	WATT: Power (kw) OHM: Accumulated power (Ω) FRQY: Frequency (Hz) CTL-M: Control method TEMP: Heatsink temperature (°C)						
	LINE3	CH3/1/2/4			1				
	LINE4	-							
3-5. Current time	LINE1	TIM-C: Current time					r		
	LINE2	YEAR: Year	MONTH: Month	DAY: Da	у		HOUR: Hour	MIN: Minute	
	LINE3	Current year	Current month	Current	day		Current hour	Current minute	
	LINE4	-							
3-6. View alarm history	LINE1	ALM-D : View alarm history (Alarm history occurence co	ndition) The SPRS o	device switches from	n a nor n 1 min	mal status (no	o alarms) to an alarm st	atus (at least one alarm active),	
		(No. of alarm history saves)	Up to 50 logs can b	e saved.					
	LINE2	LOG 01 to 50 (No alarm hist	ory, EMPTY display)						
	LINE3	2000 to 2100 (year)	1 to 12 (month)	1 to 31	(day)		0 to 23 (hour)	0 to 59 (minute)	
	OC.A: Overcurrent alarm OV.A: Overvoltage alarm OTW.A: Heatsink overheat a OTP.A: Heatsink overheat pr SCR: SCR element error alar HTBK.A: Heater break alarm	larm rotection alarm m		DLF.A: Partial heater break alarm FUSE A: Fuse break alarm FAN.A: FAN error alarm FRQY.A: Frequency error alarm LPWR.A: Input low voltage alarm PM_A: Module connection error alarm			n		
3-7 Troubleshooting		DIACH! Trade Land							
5-7. Housteshooting	LINE1	DIAGN: Trouble shooting		100.0					
	LINE2	Displays the channel set in t	the 1.1. operating ch	nannel OP-S.					
	LINE3	CTL-O: Control output value CTL-I: Control input value (9 MIN-O: Output limit MIN set MAX-O: Output limit MAX se DLF-C: Partial load scan con MPW-S: Power module statu ST-T: Soft start setting time	e (%) 6) ting (%) tting (%) npletion status us			DN-T: Soft start setting time DN-T: Soft start setting time CH1-A: Analog connection status CH2-A: Analog connection status CH3-A: Analog connection status CH4-A: Analog connection status PDC-S: Power dstribution control setting status			
		Check the setting values of t	the naramotors solo	cted in Line?		i Mir - NuITIDE			
	LIINE4	Check the setting values of the parameters selected in Line3							

[Power Module] Fuse Replacement

- Push the Slide Cover in the direction of the arrow indicated on the top of the front cover of the power module to open it and check the fuse.
- The performance of the product is guaranteed only when using the fuse provided by us. For replacing the fuse, use the recommended fuse.

■ Fuse recommended specifications

• Rated short circuit test is evaluated as a recommended fuse.

Model	Rated load current	Recommended fuse	Manufacturer	Fuse fixed bolt			
SPRS-F25	25 A	50FE	BUSSMANN				
SPRS-F40	40 A	50FE	BUSSMANN				
SPRS-F55	55 A	80ET	BUSSMANN	IND A 12, IND A 10			
SPRS-F70	70 A	100FE	BUSSMANN				
SPRS-F90	90 A	170M1368	BUSSMANN				
SPRS-F110	110 A 170M1369		BUSSMANN	M6 imes 12, M8 $ imes$ 20			
SPRS-F150	150 A	170M1370 BUSSMANN					
SPRS-F180	180 A	170M1372	BUSSMANN				
SPRS-F200	200 A	170M2620	BUSSMANN				
SPRS-F250	250 A	170M2620	BUSSMANN	M6 $ imes$ 16, M10 $ imes$ 25			
SPRS-F350	350 A	170M3471	BUSSMANN]			
SPRS-F400	400 A	170M4018	BUSSMANN				
SPRS-F500	500 A	170M4018	BUSSMANN	M10 $ imes$ 25, M10 $ imes$ 50			
SPRS-F600	600 A	170M4018	BUSSMANN				

[Power Module] Load Wiring

- Set the operating channel of the control setting mode parameters to match the actual wiring. Failure to do so may result in malfunction.
- R: Load input power
- U: Heater (load) connection
- Connecting a capacitor (CAP) across the input phase-to-neutral (A-N, B-N, C-N) or input line-to-line voltage (A-B, B-C, C-A) will ensure compliance with EMC standards. - FILM CAPACITOR: $\geq 1\mu F / 500$ VAC \sim

А

В

C N

Single-phase: 1P1

Single-phase: 1P2

Single-phase: 1P3

Feedback connector

Pin No	Pin	Function					
1	FREQ	Input power frequency detection					
2	V_IN	Input voltage measuring detection					
3	V_LOAD	Output heater voltage measuring detection					

R

Power Module

U

Т

LOAD

1

2

3

R

Power Module

U

LOAD

1

2

3

Single-phase: 1P4

Control Method

Phase control

Phase control method is to control output by dividing AC phase by control input signal. • Normal = Phase equal division method by control input

Constant current feedback control mode

Constant voltage feedback control mode

Constant power feedback control mode

It is proper control method for a heater which resistance value variation by silicon carbide (SiC) heating is big. It outputs constant power which is proportion

It outputs a constant current proportional to

the control input so that the output current does not fluctuate against fluctuations in

power voltage and load resistance fluctuations of loads (platinum, molybdenum, tungsten,

etc.) in which the temperature coefficient of

electrical resistance varies significantly from 6 to 12 times the normal temperature.

It outputs a constant voltage proportional to the control input so that the output voltage

does not fluctuate against fluctuations in power voltage and load resistance fluctuations

of loads (iron, chromium, nichrome, etc.)

to control input even though load variation and power supply variation

(B): [output voltage 50 % × output current 100 %]

Output characteristics is proper 50 % of the curve which connects the point (A) and the point (B). The current output capacity of this unit should be over two times of load capacity.

Cycle control, zero cross turn-on

Compared to the phase control method, the load control linearity is better. Since it is always ON or OFF at the zero point of AC, no noise is generated during ON / OFF, so it is a suitable control method for an environment where noise is not affected or an electric furnace with a large heat capacity.

· Fixed cycle control mode

During fixed cycle (100 cycles) of load power, it repeats ON / OFF cycle as constant ratio according to control input signal and controls the power supplies on the load

Variable cycle control mode

By minimizing the number of cycles of the load power, it controls the power applied to the load (heater) by operating ON / OFF at a ratio proportional to the control input signal

Power distribution control

- When operating up to 36 single-phase power modules, the system controls to prevent instantaneous peak power from concentrating at the same time through internal algorithm calculations between modules.
- Separate wiring work is required between control modules.

Connect the A(+) and B(-) terminals of the PDC in the control signal / communication connector of control module to the A(+) and B(-) terminals of the other control modules

Control module connection

Function

PI Coeffient

The PI controller is a control method that combines the proportional and integral coefficients to compensate for the error with respect to the target value. It is set to the optimal values from the factory settings. If the proportional and integral coefficients are arbitrarily set too small, it can lead to a fast response but may cause overshoot or hunting. If set too large, the response speed will be slower.

SOFT START

This function protects the load in cases that the set temperature is high, such as controlling the load (platinum. molybdenum, tungsten, infrared lamp, etc.) in which inrush current flows when power is supplied, or showing large width of temperature rise during initial operation.

If the input is changed before the end of the SOFT START function, T increases or decreases by the changed difference (%).

• T: SOFT START set time. Time to get the output which is applied into the load is 100 %. • T/2: Time to get the output which is applied into the load is 50 %.

SOFT UP / DOWN

Unlike SOFT START which operates only once at supplying power, this function protects load from the inrush current in the RUN mode. When reached to the target output value, operation stops

Output high / low-limit value

Input slope correction

It prevents load damage by limiting 100% of the power supplied to the load. It compensates the gain of the measured 100 % input for actual 100 % input value. Calibrated monitoring value =

Monitoring value +

Monitoring value 100 - input slope correction value

• E.g.) When the input monitoring value is 99 % at 20 mA in DC 4 - 20 mA control input, setting LINE3 of 1-9 Input slope correction = 1 % calibrates the input monitoring value to 100 %

Input OFFSET correction

It compensates the offset between actual input value and measured input value. • E.g.) When input monitoring value is 5 % at 4 mA in DC4 - 20 mA control input, setting LINE3 of 1-10 Input offset = -5.0 % calibrates the input monitoring value to 0 %.

- - : Actual input signal (%) - : Input corrected signal (%)

Partial heater break

The partial heater break alarm is available for single-phase control. When the alarm occurs, DLF.A flashes on the display (LINE1) at 0.5-second intervals, while the output is maintained.

Operating conditions

The alarm occurs when a load (heater) is disconnected (break) during single-phase 1-channel parallel load operation. A load quantity \times DEAD.Z setting current threshold or higher.

- Ex) If there are 5 loads and the DEAD.Z setting is 5A, Alarm occurence condition = 5 loads × DEAD.Z setting 5 A = 25 A
 - 25 A or higher: Alarm occurs in the power module SCAN value 25 A or lower: No alarm

Segment Table

The segments displayed on the product indicate the following meanings. It may differ depending on the product.

7 segment		11 segment			12 segment			16 segment							
٥	0	1	T	0	0	1	1	۵	0	1	T	0	0	Ţ	Ι
1	1	J	J	1	1	J	J	1	1	J	J	1	1	Ū	J
2	2	۲	K	2	2	К	К	2	2	к	К	2	2	ĸ	К
Э	3	L	L	З	3	L	L	Э	3	L	L	Э	3	L	L
ч	4	ñ	М	ч	4	Μ	М	Ч	4	М	М	Ч	4	Μ	М
5	5	n	Ν	5	5	N	Ν	5	5	N	Ν	S	5	N	Ν
6	6	٥	0	6	6	٥	0	Б	6	ο	0	б	6	۵	0
7	7	Ρ	Ρ	7	7	Ρ	Ρ	٦	7	Ρ	Ρ	ŋ	7	Ρ	Ρ
8	8	9	Q	8	8	۵	Q	8	8	۵	Q	8	8	Q	Q
9	9	r	R	9	9	R	R	9	9	R	R	9	9	R	R
R	A	5	S	R	А	5	S	Я	A	5	S	R	A	5	S
Ь	В	F	Т	Ь	В	F	Т	Ь	В	Ł	Т	3	В	Ţ	Т
C	С	U	U	٢	С	U	U	Ľ	С	U	U	٢	С	U	U
d	D	U	V	d	D	Ľ	V	d	D	Ľ	V	J	D	V	V
Ε	E	Ļ	W	Ε	Е	М	W	Ε	E	Ы	W	Ε	E	н	W
F	F	5	Х	F	F	×	Х	F	F	×	Х	F	F	×	Х
G	G	Ч	Υ	G	G	Ч	Y	6	G	Ч	Y	6	G	ř	Y
н	Н	Ξ	Z	н	Н	Z	Z	н	Н	Z	Z	Н	Н	2	Ζ